

Grease Traps











WHAT IS A GREASE TRAP?

Netco Grease Traps are specifically designed to prevent fats, oils, grease and solids from entering the sewer system. A Grease Trap slows the flow of warm/hot greasy wastewater and allows it to cool. As the water cools, suspended fats, oils and grease will separate and float to the top, and solids will drop out and settle on the bottom. This leaves the cleaner, cooler water to discharge to sewer.

HOW DO I KNOW IF I NEED A GREASE TRAP?

Wastewater that includes fats, oils and grease is categorised as Trade Waste. The local governing authority which manages trade waste in your area will determine if your business requires a grease trap, and they will have a set of criteria to determine your required grease trap capacity. You will need to set up a formal trade waste agreement with your local authority and they will need to approve the size and location of your grease trap before being allowed to discharge trade waste to sewer.

Typical businesses which would require a grease trap would include the following:



Bakeries











Outlets

Centres







SPECIFICATIONS

Netco Grease Traps are available in standard sizes from 1000L to 5000L capacity in both above-ground and below-ground configuration. Custom-size Grease Traps are also available, and we offer complimentary site visits to measure up and ensure our clients get exactly what they need.

ABOVE GROUND

Model	Capacity (L)	Length (mm)	Width (mm)	Height (mm)	Water Level (mm)	Weight (kg)
PRE1000-GT/AG-PT	1000	1810	1030	1076	706	80
PRE1500-GT/AG-PT	1500	2630	1130	1076	706	140
PRE2000-GT/AG-PT	2000	2630	1250	1076	706	160
PRE2500-GT/AG-PT	2500	2630	1130	1396	1026	220
PRE3000-GT/AG-PT	3000	2630	1130	1596	1226	250
PRE4000-GT/AG-PT	4000	2630	1730	1400	1030	280
PRE5000-GT/AG-PT	5000	2630	1730	1680	1310	330

BELOW GROUND

Model	Capacity (L)	Length (mm)	Width (mm)	Height (mm)	Water Level (mm)	Tank Weight (kg)	Cover Weight (kg)	
							Class B	Class D
PRE1000-GT/BG-PT	1000	1800	1000	1370	1010	125	80	135
PRE1500-GT/BG-PT	1500	2400	1000	1470	1110	160	105	170
PRE2000-GT/BG-PT	2000	3000	1000	1530	1170	195	130	215
PRE2500-GT/BG-PT	2500	3000	1400	1570	1210	220	150	250
PRE3000-GT/BG-PT	3000	3600	1300	1560	1200	250	170	300
PRE4000-GT/BG-PT	4000	3600	1400	1940	1580	300	170	300
PRE5000-GT/BG-PT	5000	4700	1400	1810	1450	355	250	415

Trade Waste in Tasmania is managed by TasWater. For any Trade Waste enquiries you can contact their Trade Waste Hotline on (03) 6422 5444 or email tradewaste@taswater.com.au. There is also helpful information available at www.taswater.com.au/Customers/Trade-Waste.



Hobart

100 Sunderland St Derwent Park TAS 7009

Ph: 1300 301 664

Burnie

16-18 Wellington St South Burnie TAS 7320

Ph: 1300 301 664

PO Box 800 Moonah TAS 7009

